



CU-LT FIRE DAMPER




TECHNICAL FEATURES

- Damper range (WxH): 200x100 till 800x600.
- Damper can be installed with blade in vertical or horizontal position.



- Damper can be installed with mechanism on either side of the wall (independent of fire side).
- Please consult with the fire batt manufacturer for appropriate sealant/ coating.
- More info on larger wall openings. See CU-LT Fire Damper installation manual.
- A max. of 2x2 fire dampers can be installed at tested minimal distances from an adjacent horizontal or vertical (supporting) construction or another fire damper. See detailed guidelines in the CU-LT installation manual.



- To be read in conjunction with the CU-LT Fire Damper installation manual.
- Guidelines acc. to DW144/145 (not required for CE certification):
 - Installation lugs as shown in the drawings are available upon request.
 - Provide appropriate break-away / flexible joint between fire damper and connecting ductwork on both sides of the assembly (DW145: Breakaway and flexible joints should incorporate materials, fixings, clamps, etc. that are manufactured from non-fire-resistant material with a low melting point such as aluminium, plastic etc.).
 - Provide space to access the internal components of a damper through an adjacent ductwork opening. Rf-T can provide an inspection opening on the damper body upon request (option UL).
 - Supports to the connecting ductwork should be provided in accordance with the requirements of BESA Specification DW/144.
- Dimensions in mm unless otherwise stated.

INSTALLATION MANUAL



INSPECTION AND HANDOVER CHECK LIST



PLAN TITLE

CU-LT fire damper in flexible supporting construction.
Installation detail with fire batt.

PAGE

1/1

CLASSIFICATION

EI 60/90 (ve i↔o)S



REV

C


DATE

20/08/2025




Rf-Technologies

CU-LT FIRE DAMPER




TECHNICAL FEATURES

- Damper range (WxH): 200x100 till 800x600.
- Damper can be installed with blade in vertical or horizontal position.



- Damper can be installed with mechanism on either side of the wall (independent of fire side).
- Please consult with the fire batt manufacturer for appropriate sealant/ coating.
- More info on larger wall openings. See CU-LT Fire Damper installation manual.
- A max. of 2x2 fire dampers can be installed at tested minimal distances from an adjacent horizontal or vertical (supporting) construction or another fire damper. See detailed guidelines in the CU-LT installation manual.



- To be read in conjunction with the CU-LT Fire Damper installation manual.
- Guidelines acc. to DW144/145 (not required for CE certification):
 - Installation lugs as shown in the drawings are available upon request.
 - Provide appropriate break-away / flexible joint between fire damper and connecting ductwork on both sides of the assembly (DW145: Breakaway and flexible joints should incorporate materials, fixings, clamps, etc. that are manufactured from non-fire-resistant material with a low melting point such as aluminium, plastic etc.).
 - Provide space to access the internal components of a damper through an adjacent ductwork opening. Rf-T can provide an inspection opening on the damper body upon request (option UL).
 - Supports to the connecting ductwork should be provided in accordance with the requirements of BESA Specification DW/144.
- Dimensions in mm unless otherwise stated.

INSTALLATION MANUAL



INSPECTION AND HANDOVER CHECK LIST



PLAN TITLE

CU-LT fire damper in flexible supporting construction.
Installation detail with fire batt and coating on the damper tunnel.

PAGE

1/1

CLASSIFICATION

EI 120 (ve i↔o)S



REV


C

DATE

20/08/2025




Rf-Technologies




TECHNICAL FEATURES

- Damper range (WxH): 200x100 till 800x600.
- Damper can be installed with blade in vertical or horizontal position when using gypsum plaster.
- If mortar : installation with blade in horizontal position.



- Damper can be installed with mechanism on either side of the wall (independent of fire side).
- A max. of 2x2 fire dampers can be installed at tested minimal distances from an adjacent horizontal or vertical (supporting) construction or another fire damper. See detailed guidelines in the CU-LT installation manual. When using mortar as sealant, install with damper blade in horizontal position.



- To be read in conjunction with the CU-LT Fire Damper installation manual.
- Guidelines acc. to DW144/145 (not required for CE certification):
 - Installation lugs as shown in the drawings are available upon request.
 - Provide appropriate break-away / flexible joint between fire damper and connecting ductwork on both sides of the assembly (DW145: Breakaway and flexible joints should incorporate materials, fixings, clamps, etc. that are manufactured from non-fire-resistant material with a low melting point such as aluminium, plastic etc.).
 - Provide space to access the internal components of a damper through an adjacent ductwork opening. Rf-T can provide an inspection opening on the damper body upon request (option UL).
 - Supports to the connecting ductwork should be provided in accordance with the requirements of BESA Specification DW/144.
- Dimensions in mm unless otherwise stated.

INSTALLATION MANUAL



INSPECTION AND HANDOVER CHECK LIST



PLAN TITLE

CU-LT fire damper in flexible supporting construction
Installation detail with gypsum plaster or mortar

PAGE

1/1

CLASSIFICATION

EI 60/90 (ve i↔o)S



REV

C


DATE

20/08/2025



Rf-Technologies

CU-LT FIRE DAMPER



TECHNICAL FEATURES

- Damper range (WxH): 200x100 till 800x600.
- Install the damper with the blade in horizontal position.



- Damper can be installed with mechanism on either side of the wall (independent of fire side).
- Based on our CE certification, the damper may be installed remote from wall at any distance.
- Please consult with the fire batt manufacturer for appropriate sealant/coating.
- A max. of 2x2 fire dampers can be installed at tested minimal distances from an adjacent horizontal or vertical (supporting) construction or another fire damper. See detailed guidelines in the CU-LT installation manual.



- To be read in conjunction with the CU-LT Fire Damper installation manual.
- Guidelines acc. to DW144/145 (not required for CE certification):
 - Provide appropriate break-away / flexible joint between fire damper and connecting ductwork on both sides of the assembly (DW145: Breakaway and flexible joints should incorporate materials, fixings, clamps, etc. that are manufactured from non-fire-resistant material with a low melting point such as aluminium, plastic etc.).
 - Provide space to access the internal components of a damper through an adjacent ductwork opening. Rf-T can provide an inspection opening on the damper body upon request (option UL).
 - Supports to the connecting ductwork should be provided in accordance with the requirements of BESA Specification DW/144.
- Dimensions in mm unless otherwise stated.

INSTALLATION MANUAL



INSPECTION AND HANDOVER CHECK LIST



PLAN TITLE

CU-LT fire damper remote from a flexible supporting construction. Installation detail with IFW installation block and fire batt

PAGE

1/1

CLASSIFICATION

EI 60/90 (ve i↔o)S



REV

D

DATE

23/10/2025



Rf-Technologies